

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PASSENGER AUDIO FITS GL1800
CONTROLLER GOLDWING
PART NO. 13-203

TOOLS NEEDED:

6 MM ALLEN WRENCH

INSTALLATION:

1. USING A 6MM ALLEN WRENCH, REMOVE THE FOUR SEAT BOLTS LOCATED IN THE REAR HANDLES FOR THE PASSENGER.
2. WITH THE BOLTS REMOVED, PULL UP ON THE REAR OF THE SEAT TO REMOVE FROM BIKE. IT IS A TIGHT FITTING SEAT AND CAN BE DIFFICULT TO REMOVE. IF YOU PULL A REAR CORNER UP FIRST AND WORK IT PAST THE PASSENGER BACKREST, THE SEAT SHOULD COME OFF.
3. WITH THE SEAT REMOVED, LOCATE THE STOCK PASSENGER 5 PIN DIN HEADSET WIRE HARNESS AND REMOVE FROM THE 6 PIN WHITE FEMALE CONNECTOR BY FOLLOWING THE WIRE ON THE HEADSET PLUG TO THE CONNECTOR. THIS CONNECTOR IS LOCATED WITHIN A BLACK DUST BOOT NEXT TO THE RELAY BOX ON THE LEFT SIDE. ONCE THIS IS FOUND UNPLUG THE CORD. THIS CORD IS NO LONGER NEEDED.
4. TAKE THE NEW 13-203 6 PIN PLUG AND PLUG IT INTO THE CONNECTOR FROM WHERE THE OLD CORD WAS LOCATED.
5. FIND THE BLACK MALE 2 PIN CONNECTOR LOCATED IN THE BLACK RUBBER DUST BOOT BEHIND THE RELAY BOX AND PLUG THE WHITE FEMALE 2 PIN CONNECTOR FROM THE 13-203 INTO IT.
6. ROUTE THE CORD HOWEVER IT IS DESIRED SO THAT THE PLUG REACHES THE CORD HOLDER ON THE LEFT SIDE OF THE TRUNK.
7. REPLACE THE SEAT AND FASTEN WITH THE HARDWARE REMOVED IN STEP 1.
8. THE CONTROL BOX CAN BE ATTACHED WITH THE VELCRO WHEREVER DESIRED WHEN IN USE. SUGGESTED LOCATION IS ON THE LEFT PASSENGER HANDLEBAR.

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PASSENGER AUDIO FITS GL1800
CONTROLLER GOLDWING
PART NO. 13-203

TOOLS NEEDED:

6 MM ALLEN WRENCH

INSTALLATION:

1. USING A 6MM ALLEN WRENCH, REMOVE THE FOUR SEAT BOLTS LOCATED IN THE REAR HANDLES FOR THE PASSENGER.
2. WITH THE BOLTS REMOVED, PULL UP ON THE REAR OF THE SEAT TO REMOVE FROM BIKE. IT IS A TIGHT FITTING SEAT AND CAN BE DIFFICULT TO REMOVE. IF YOU PULL A REAR CORNER UP FIRST AND WORK IT PAST THE PASSENGER BACKREST, THE SEAT SHOULD COME OFF.
3. WITH THE SEAT REMOVED, LOCATE THE STOCK PASSENGER 5 PIN DIN HEADSET WIRE HARNESS AND REMOVE FROM THE 6 PIN WHITE FEMALE CONNECTOR BY FOLLOWING THE WIRE ON THE HEADSET PLUG TO THE CONNECTOR. THIS CONNECTOR IS LOCATED WITHIN A BLACK DUST BOOT NEXT TO THE RELAY BOX ON THE LEFT SIDE. ONCE THIS IS FOUND UNPLUG THE CORD. THIS CORD IS NO LONGER NEEDED.
4. TAKE THE NEW 13-203 6 PIN PLUG AND PLUG IT INTO THE CONNECTOR FROM WHERE THE OLD CORD WAS LOCATED.
5. FIND THE BLACK MALE 2 PIN CONNECTOR LOCATED IN THE BLACK RUBBER DUST BOOT BEHIND THE RELAY BOX AND PLUG THE WHITE FEMALE 2 PIN CONNECTOR FROM THE 13-203 INTO IT.
6. ROUTE THE CORD HOWEVER IT IS DESIRED SO THAT THE PLUG REACHES THE CORD HOLDER ON THE LEFT SIDE OF THE TRUNK.
7. REPLACE THE SEAT AND FASTEN WITH THE HARDWARE REMOVED IN STEP 1.
8. THE CONTROL BOX CAN BE ATTACHED WITH THE VELCRO WHEREVER DESIRED WHEN IN USE. SUGGESTED LOCATION IS ON THE LEFT PASSENGER HANDLEBAR.