



15673-818K
Mounting Instructions for
GL1500 Passenger Armrests



Note: Read instructions thoroughly before installing.

MUST HAVE TWO ANTENNAS FOR APPLICATION.

1. Place bike on center stand.
2. Mount pads onto armrest brackets.
3. Open the trunk and remove the three screws that hold on the storage pouch. Remove the pouches.
4. Remove the two bolts that hold the antennas.
5. Slide the armrest bracket between the antenna and the trunk. Make sure the antenna wire goes into the slot.
6. Reinstall bolts to both antennas.
7. Reinstall storage pouches.

NOTE: Brass washer are used to tighten pivot points (IF needed)

NOTE: Chrome plug are used to fill holes in flat chrome plate.