

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 20-514T,
20-515, 20-516, 20-516T,
20-517, 20-518 & 20-518T

WINDSHIELD
GL1800 GOLDWING

Revised 09/22/08

TOOLS REQUIRED: 10 MM WRENCH 5MM ALLEN WRENCH PHILLIPS SCREWDRIVER

NOTE: SET THE BIKE SECURELY ON ITS CENTER STAND TO MAKE INSTALLATION EASIER AND SAFER.

1. RELEASE THE HEIGHT LEVERS (1A). FIG. 1
2. REMOVE THE RUBBER COVER (1B) AROUND THE MIRRORS. FIG. 1.
3. USING A 10MM WRENCH REMOVE THE BOLT (2A), WASHER (2B), AND RUBBER (2C) HOLDING THE WINDSHIELD GARNISH (2D) ON. FIG. 2
4. REMOVE THE WINDSHIELD GARNISH (2D) BY PULLING THE BOSSES OUT OF THE GROMMETS. FIG. 2
5. USING A 5MM WRENCH REMOVE THE SIX SCREW (3A) HOLDING THE WINDSHIELD (3B) TO THE DASH, REMOVE THE METAL CLIPS (3C). FIG. 3
6. PULL THE WINDSHIELD (3B) OUT. FIG. 3
7. REMOVE THE CENTER METAL CLIP (3D) BY REMOVING THE PHILLIPS SCREW. FIG 3
8. INSTALL THE NEW WINDSHIELD BY REVERSING STEPS 1 THROUGH 6.

