



**MOUNTING INSTRUCTION FOR
GL1800 2012 Chrome Saddlebag Scuff Cover Inserts
PART NUMBER 45-1898**

Note: Read instruction thoroughly before installing. No hardware is needed to install inserts.

1. Place bike on center stand.
2. Working one side at a time, place insert in opening.
3. Gently push insert into opening in saddlebag scuff cover until you hear it snap in.
4. Repeat on other side.



133 Gold St, Worcester, MA 01608 508-791-7552 Fax 508-793-2919 800-821-9861
email: info@addonaccessories.net