

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

PART NO. 52-798

EXHAUST TIPS
FOR HONDA GL1800 GOLDWING

Revised 7/9/2012

TOOLS REQUIRED: 8MM SOCKET WRENCH

CAUTION: ALLOW ENGINE AND EXHAUST SYSTEM TO COOL BEFORE INSTALLING NEW EXHAUST TIPS.

INSTALLATION:

NOTE: EXHAUST TIP ENDS CAN BE ROTATED TO CUSTOMIZE STYLE WITH BIKE. TO ROTATE REMOVE BOLTS INSIDE SLEEVE, ROTATE TIP END, AND REATTACH WITH SCREWS. (A 6 INCH (152MM) EXTENSION IS REQUIRED)

1. PLACE BIKE ON CENTER STAND.
2. USING 8MM SOCKET WRENCH REMOVE THE 3 SCREWS (ALONG WITH LOCK WASHERS AND FLAT WASHERS) LOCATED ON THE BOTTOM AND INSIDE OF THE OEM EXHAUSTED TIPS.
3. FROM THE REAR OF THE BIKE SLIDE THE OEM EXHAUST TIPS OFF.
4. LOOK INSIDE THE NEW EXHAUST TIP NEXT TO THE MOUNTING HOLES AND FIND THE MARKING THAT IS STAMPED ON IT. THE ONE STAMPED "L" IS FOR THE LEFT SIDE AND THE ONE MARKED "R" IS FOR THE RIGHT SIDE.
5. SLIDE ON THE NEW EXHAUST TIPS. USE THE SCREWS AND WASHERS REMOVED IN STEP #2. FASTEN THE CENTER SCREW FIRST AS THIS WILL ALLOW THE OTHER HOLES TO ALIGN WITH SOME ADJUSTABILITY.

PLEASE NOTE: EACH BIKE'S EXHAUST WELDMENT FIT MAY VARY. IF NECESSARY, SLIGHTLY ENLARGE THE HOLES IN THE MOUNTING BRACKETS (BRACKETS ARE WELDED INSIDE OF THE NEW EXHAUST TIP SLEEVES).



Video