

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-931

REAR FENDER FILLER

12/3/2018

FITMENT: HONDA GOLDWING 2018-NEWER

TOOLS NEEDED: 5MM ALLEN WRENCH

RUBBING ALCOHOL

CLEAN RAG

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**ESTIMATED INSTALLATION TIME: 15 TO 20 MIN.****INSTALLATION:**

1. REMOVE THE TWO ALLEN SCREWS HOLDING THE REAR FENDER (FIG. 1).
2. PULL STRAIGHT BACK ON THE BOTTOM OF THE FENDER TO RELEASE THE RUBBER GROMMET. THEN PULL STRAIGHT BACK ON THE TOP TO RELEASE THE REAR FENDER.
3. UNPLUG THE LICENSE PLATE LIGHT CONNECTOR (FIG. 2).
4. DETERMINE WHICH IS THE LEFT AND RIGHT FENDER FILLERS ACCORDING TO FIG. 3.
5. USE RUBBING ALCOHOL TO CLEAN THE AREAS SHOWN IN FIG. 4. LET DRY COMPLETELY.
6. REMOVE THE BACKER FROM THE LEFT FENDER FILLER TAPE.
7. PLACE THE TOP MOUNT TAB OF THE LEFT FENDER FILLER OVER THE REAR FENDER TAB SO THE RIBS ARE FACING YOU.
8. FIRMLY PRESS THE DOUBLE SIDED TAPE IN PLACE ON THE REAR FENDER TO SECURE. (FIG. 4).
9. REPEAT STEPS 6 THROUGH 8 ON THE RIGHT SIDE.
10. REASSEMBLE THE BIKE IN REVERSE ORDER.

