

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright® 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 53-429

7" CHROME HEADLIGHT VISOR

PART NO. 63-114

CELESTAR 7" HEADLIGHT VISOR

TOOLS NEEDED: PHILLIPS SCREWDRIVER    NEEDLE NOSE PLIERS    SILICONE    SHIMS

1. REMOVE ONE COUNTERSUNK PHILLIPS HEAD SCREWS FROM EACH SIDE OF THE HEADLIGHT HOUSING. PULL THE HEADLIGHT OUT OF THE HOUSING AND DISCONNECT THE PLUG FROM THE HEADLIGHT SO IT IS COMPLETELY REMOVED FROM THE BIKE.
2. TAKE NEEDLE NOSE PLIERS AND REMOVE THE CHROMING TABS FROM THE BACK FLANGE OF THE HEADLIGHT VISOR. THEN PLACE THE HEADLIGHT VISOR THRU THE RETAINING RING FROM THE FRONT SO THAT THE BACK FLANGE IS PUSHED TIGHT AGAINST THE BACK FACE OF THE RETAINING RING, MAKING SURE THE VISOR IS ALSO PUSHED TIGHT AGAINST THE INSIDE EDGE OF THE RETAINING RING SO IT FOLLOWS THE SAME CONTOUR.

**NOTE: ON SOME HEADLIGHTS THE BACK FLANGE MAY NEED TO BE TRIMMED TO ALLOW FOR CLEARANCE OF HEADLIGHT LOCATOR CLIPS.**

3. PLACE SHIMS BETWEEN THE HEADLIGHT AND THE VISOR TO SECURE THE VISOR AGAINST THE RETAINING RING, THEN LAY A BEAD OF CLEAR OR CLEAR DRYING SILICONE OVER THE BACK FLANGE OF THE HEADLIGHT VISOR AND THE RETAINING RING TO PERMANENTLY SECURE THE TWO TOGETHER. ONCE THE SILICONE IS DRY REMOVE THE SHIMS.
4. REPEAT STEP ONE IN REVERSE ORDER TO REPLACE THE HEADLIGHT.