

# GOLDSTRIKETM FRONT FENDER EXTENSION

Parts Included: 1

Front fender extension

Fender filler strip hardware kit

## **INSTALLATION INSTRUCTIONS:**

- 1. Park on a level surface and shut off the motorcycle. Lift motorcycle onto its center stand if available. Ensure the engine has time to cool before installation.
- 2. Test fit the fender extension to familiarize yourself with its location. Then clean the inside of the front fender in the mounting area with hot water and soap to remove all dirt and debris.
- 3. Attach the included drill template stickers aligning it to the front and botom edges to the fender. (FIG.1)
- 4. Use a 1/4" or 6mm drill bit and carefully drill through the fender on both sides then remove the template stickers. ATTENTION: Use a piece of wood or other hard material to protect the tire from the drill bit. (FIG.1)
- 5. ATTENTION: Thoroughly clean the mounting surfaces with denatured alcohol to remove all wax, oil, and residue.

  NOTE: New motorcycles are delivered from the factory covered in protective oil. Remove it before installing this product.

  NOTE: Do not install if the temperature is below 50° F. The adhesive will not cure properly.
- 6. Apply the adhesion promoter to the mounting area on the inside of the fender following the directions on the package.
- 7. Remove the red adhesive backer and carefully install the fender extension. Firmly press the extension to the fender.
- 8. Install the square nuts on the inside of the fender and thread the M6 x 8mm BHCS into them. (FIG.2, FIG.3) Torque to 5 lbf.-ft. 8 N-m





### WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

#### **CAUTION:**

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

#### ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

#### NOTE:

Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit our website Ciro3d.com for our complete warranty policy.

Goldstrike3D.com



