



## FRONT MIRROR ACCENTS 380

## Parts included:

Mirror Accent Right Side	1
Mirror Accent Left Side	1
Alcohol Pad	7

- 1. Park and Shut down the bike.
- 2. Clean the mounting surfaces.
- 3. Test fit items to familiarize left and right sides.
- 4.Clean mounting surfaces with included alcohol pads. Mounting surfaces must be without wax, oil and residue.

  DO NOT install if the temprature is below 50F. The adhesive will not cure properly.
- 5. After place the accents, apply pressure for 60 seconds. The adhesive cures within 24 hours.

## **WARNING:**

Ignoring the instruction may result in potential serious injury, death or material damage.

## **Limited Warranty:**

Products are warranted to be free of defects in material and workmanship for 1 (one) year from date of purchase by the consumer.

Customer must show proof of purchase for warranty.

Twinart shall not be liable for any consequential and incidental damages.

The products must be installed properly and operated under normal conditions.