## **BIG BIKE PARTS**<sup>®</sup> INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

## INSTALLATION

FAIRING SIDE LIGHT HARNESS PART NO. 2-281 FOR HONDA GL1500/6 GOLD WING MODELS

Revised 1/29/2009

ITEMS REQUIRED: FLAT BLADE SCREWDRIVER, #2 PHILLIPS SCREWDRIVER 1. REMOVE L/R SIDE COVERS, 1A, 2A. 2. REMOVE L/R FAIRING POCKETS, 1B, 2B. REMOVE L/R SIDE LIGHTS, 1C, 2C. 3. UNPLUG L/R RUBBER CAPS FROM BACK OF SIDE LIGHTS, 1D, 2D 4. 5. PLUG LIGHT HARNESS INTO L/R SIDE LIGHTS 1E, 2E. RUN GREEN WIRE HARNESS CONNECTOR THROUGH R/H FAIRING (FIG. 3) AND PLUG INTO GREEN TWO PIN CONNECTOR, 3A. 6. REPEAT STEP 6 FOR L/H FAIRING (NOT ILLUSTRATED). 7. 8. REINSTALL L/R COVERS AND L/R FAIRING POCKETS. (RIGHT SIDE) (LEFT SIDE) FAIRING POCKET, (R) (2B) FAIRING POCKET, (L) (1B PART B PART A FAIRING FAIRING SIDE COVER, (R) (2A) SIDE LIGHT, (R) (2C) RUBBER CAP (2D) RUBBER CAP SIDE LIGHT, (L) (1C) SIDE COVER, (L) (1A) (1D) FIGURE 2 FIGURE 1 GREEN TWO PIN CONNECTOR (3A) AIR DUCT FIGURE 3 (R/H)