

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

BRAKE LEVER
PART NO. 18-101

FOR GL1500
1990-2000


Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

TOOLS REQUIRED: 10 MM WRENCH
FLAT BLADE SCREWDRIVER
2.5 MM ALLEN WRENCH

1. REMOVE THE 10 MM NUT ON THE BOTTOM SIDE OF THE BRAKE LEVER ATTACHMENT SCREW.
2. USING THE SCREWDRIVER REMOVE THE BRAKE LEVER ATTACHMENT SCREW & CAREFULLY REMOVE THE LEVER.
3. CAREFULLY INSTALL THE (2) ALLEN HEAD SCREWS PROVIDED INTO THE NEW LEVER. (SEE FIG. 1) DO NOT SCREW THEM IN PAST THE FACE OF THE LEVER AT THIS TIME.
4. REINSTALL THE LEVER BY REVERSING STEPS ONE & TWO.
5. CHECK THE LEVER, SHOULD BE ABLE TO DIS-ENGAGE FREELY.

IMPORTANT: STEPS 6 & 7

6. WITH THE LEVER IN THE RELEASED POSITION, ADJUST THE (2) ALLEN HEAD SCREWS (ONE AT A TIME) TO ACTIVATE THE SWITCHES.
NOTE: THESE ARE VARY INTRICATE SETTINGS. DO NOT OVER ADJUST.
7. THE SWITCHES MAKE A "CLICK" SOUND WHEN ENGAGED & DIS-ENGAGED. MAKE SURE THE SWITCHES ARE WORKING PROPERLY BEFORE USE.
8. ONCE THE SETTINGS ARE DONE THE NYLOC INSERTED SCREWS WILL RETAIN THEIR POSITION.



BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

BRAKE LEVER
PART NO. 18-101

FOR GL1500
1990-2000

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

TOOLS REQUIRED: 10 MM WRENCH
FLAT BLADE SCREWDRIVER
2.5 MM ALLEN WRENCH

1. REMOVE THE 10 MM NUT ON THE BOTTOM SIDE OF THE BRAKE LEVER ATTACHMENT SCREW.
2. USING THE SCREWDRIVER REMOVE THE BRAKE LEVER ATTACHMENT SCREW & CAREFULLY REMOVE THE LEVER.
3. CAREFULLY INSTALL THE (2) ALLEN HEAD SCREWS PROVIDED INTO THE NEW LEVER. (SEE FIG. 1) DO NOT SCREW THEM IN PAST THE FACE OF THE LEVER AT THIS TIME.
4. REINSTALL THE LEVER BY REVERSING STEPS ONE & TWO.
5. CHECK THE LEVER, SHOULD BE ABLE TO DIS-ENGAGE FREELY.

IMPORTANT: STEPS 6 & 7

6. WITH THE LEVER IN THE RELEASED POSITION, ADJUST THE (2) ALLEN HEAD SCREWS (ONE AT A TIME) TO ACTIVATE THE SWITCHES.
NOTE: THESE ARE VARY INTRICATE SETTINGS. DO NOT OVER ADJUST.
7. THE SWITCHES MAKE A "CLICK" SOUND WHEN ENGAGED & DIS-ENGAGED. MAKE SURE THE SWITCHES ARE WORKING PROPERLY BEFORE USE.
8. ONCE THE SETTINGS ARE DONE THE NYLOC INSERTED SCREWS WILL RETAIN THEIR POSITION.

